VM-2500SE
Console Connector
Pin Codes

J1 Connector

aa	Program Out 1
bb	Program Out 2
A	RS-485 A
B	RS-485 B
1	+12 VDC SW OUT – MODULE
2	GND – MODULE
V	+12 VDC SW OUT - AUX
W	GND - AUX
ff	AUX SENSOR SIGNAL
3	+V BATTERY
4	GND BATTERY

J2 Connector (GPS Models only)

11	TxD
12	RxD
13	DTR
14	DSR
15	GND